



USER MANUAL

TWT – 01



Specifications:

1. Accuracy: Class III
2. Sensitivity: 1.5~3.0mV/V
3. Nonlinear: $\leq 0.01\%$ F.S
4. Working Voltage: DC:5V
5. Speed: 10times/seconds(optional)
6. Internal Resolution: 500000~1500000

Power Source

100~240V 50/60hz AC INPUT

12V/1A DC OUTPUT

6V/4AH Lead-acid rechargeable battery included

Low battery warnings

The display battery symbol lights up when battery voltage is lower than 5.6 V

The display battery symbol starts to flash when battery voltage is lower than 5.5V

The scale will shut off automatically when battery voltage is lower than 5.4V

Preparation:


1. Please send this product is placed in the firm and flat place, don't place in vibration or shaking. And adjust four feet to keep the product stable, adjust the level bubble to keep it in the level place.
2. Please use the current independently to avoid the interference of other electronics.
3. Please put nothing on the plate when switch on the power.
4. Please turn on 2-3 minutes before using.
5. Please avoid setting the products in the place where the humidity changing is over 80%.
6. Please put the things in the middle of the plate to keep the accuracy.

Power Consumption

1. Approx.12mA
2. Approx.36mA with backlight
3. Approx.48mA with backlight and RS232 interface
4. Battery hours per charge: Approx.120hours

Load cell connection (for indicator)

1. The plug of load cell , see the following drawing
2. Do not plug the connection when the indicator is on to protect the indicator and load cell.



PIN 1: EXC+
PIN 3: SIG+
PIN 5: SHIELD

PIN 2: EXC-
PIN 4: SIG-

Counting function specification

If in unit setup mode, set the pieces, then activate counting function , operate specification as below:

1. Press **【UNITS】** key for two seconds, it shows “0” in the display. At the same time, the light of “PCS” is lit up.
2. Press **【net/gross】** key ,it shows “10” ,press **【net/gross】** key ,choose the quantity of the sample in turn.
3. Put the goods on the plate , press **【print】** key to confirm, it shows the quantity of the sample in the display.
4. In counting model, , press and hold **【UNITS】** key to back to weighing model.

Remark :The unit weight of the sample is less than 0.2d, it can not do the sample.

Function Key:

OFF: Press and hold the **OFF** key, the display will show “off” for 2 seconds then the scale will turn off automatically

ON: Turn on the scale

UNITS/ESC: Units: To select desired weighing unit.
Esc: To escape setting in setup mode.

ZERO/◀: ZERO: To reset the weight to 0, but the displayed weight value has to be less than $\pm 2\%$ of maximum capacity.
: To move one space to the left or downward in setup mode.

TARE/▶: Tare: To subtract the container weight. Maximum tare = full capacity.
: To move one space to the right or upward in setup mode.

Net/Gross /▲: Net/Gross: To see gross and net weight when the scale is on tare status.

All other key will be disabled when gross weight is activated.

▲: To increase values upward in setup mode.

PRINT: Manually transmitting data through RS232 to computer or printer at normal weighing mode(RS232 setup must be set at keyboard transmission 232 3 or 232 6)

Functions keys of special kinds of scale(CWB22、CWT22):

PT: Press **PT** key, enter in the weight of the container and then put the container on the plate. It shows the weight of the goods in the display.

HI: To set check weighing high weight:

LO: To set check weighing low weight

I/O SET: To program check weighing I/O conditions

M+/9: Accumulation key

Press this key; it can accumulate the total weights and total times. In setting model, it means numeric number 9. It can accumulate at most 9999 times.

RECALL/6: To display total accumulation count and total accumulated weight. In setting model, it means numeric number 6.

MC/ 3: Memory Clear key to clear all accumulated weight data (When the weighing unit is changed (ex: from kg to lb), all accumulated data will be cleared automatically) (display cursor M+ lights off). In setting model, it means numeric number 3.

SAMPLE/ 8: press this key to enter in sample mode. In setting model, it means numeric number 8.

COUNT/5: Counting key. Press this key to enter in counting mode. In setting model, it means numeric number 5.

☾/2: To select “Lit. A” auto backlight, “Lit. on” backlight ON or “Lit oFF” backlight OFF. Works as numeric number 2 in setup mode

CE: Clear key

Standard functions operate

1. Display internal value and voltage

In weighing mode, press and hold **【Tare】**key, and then press **【Print】**key, display UF-1, and then press **【Print】** key, display internal value , and then press **【Print】** key, display BAT X.X,X.X which means battery voltage. Press **【UNITS】** key twice to back to weighing model.

2. Check Weighing

In weighing mode, press and hold **【Tare】**key, and then press **【Print】**key, display UF-1, and then press **【Tare】**key, display UF-2, press **【print】**key, display 00000L, set low weight, press **【print】** key, display 00000H, set high weight. press **【print】** key, it shows b 000 to set the condition of beeping.

The method of setting high or low weight: press **【net/gross】** key to change number, press **【ZERO】** key to move cursor to left or press **【tare】** key to move cursor to right. And the low weight must be less than the high weight.

3. Auto power-off

In the weighing model, press and hold【tare】key, and then press【print】key, it shows UF-1. Press 【tare】 key twice, it shows UF-3. Press 【print】 key, it shows A OFF 00, press【zero】key to move cursor to left or press【tare】key to move cursor to right. Press 【net/gross】 key to add number, the number means the time of power off. For example, the setting number is 01, when the weight in the plate is less than 9d and the indicator does not work in one minute, the indicator will be power-off automatically. Press 【print】 key to confirm, and press 【units】 key to back to weighing model.

4. Backlight

In the weighing model, press and hold【tare】key, and then press【print】key, it shows UF-1. Press 【tare】 key for three times, it shows UF-4. Press 【print】 key, it shows Lit A (auto backlight) . Press 【net/gross】 key, it shows Lit on (backlight on) , Lit OFF (backlight off) . Press 【print】 key to confirm, and press 【units】 key to back to weighing model.

5.RS 232 (option)

In the weighing model, press and hold【tare】key, and then press【print】key, it shows UF-1. Press 【tare】 key for five times, it shows UF-6. Press 【print】 key, it shows 232 0(factory default: no), Press 【print】 key to choose 1-10:

Form	Output	Form	Output
1		2	
232 1	Stable output	232 4	Stable output
232 2	Stream output	232 5	Stream output
232 3	Press【print】key output	232 6	Press【print】key output
Form	Output	Form	Output
3		4	
232 7	Accumulative output	232 9	Accumulative output
232 8	Auto-accumulative output	232 10	Auto-accumulative output

6. Weighing speed

In the weighing model, press and hold【tare】key, and then press【print】key, it shows UF-1. Press 【tare】 key for six times, it shows UF-7. Press 【print】 key, it shows SPEEd 1 (factory default), press 【net/gross】 key to choose 1-3.

1: standard speed 2: fast speed 3: slow speed

7. Display condition at zero

In the weighing model, press and hold【tare】key, and then press【print】key, it shows UF-1. Press 【tare】 key for seven times, it shows UF-8. Press 【print】 key, it shows Z P 1, press 【net/gross】 key to choose 1-5, the number ,means the quantity of divisions not display at zero. Press 【print】 key to confirm, and press 【units】 key to back to weighing model.

8. G value

In the weighing model, press and hold【tare】key, and then press【print】key, it shows UF-1. Press 【tare】 key for eight times, it shows UF-9. Press 【print】key, it shows -00-, and then shows 9.79423 (G value of the manufacturing place) . And then press 【print】 key to adjust the G value of the using place, the first number in the left begins to twinkle, and press 【net/gross】 key to choose the number. Press 【ZERO】 key to move cursor to left or press 【tare】 key to move cursor to right. Press 【print】 key to confirm, and press 【units】 key to back to weighing model.

Calibration:

1. Weight and zero calibration

In the weighing model, press and hold 【print】 key, and then press 【ZERO】 key, it shows ECF-1. Press 【print】 key, it shows CAL Z to begin zero calibration. Press 【print】 key, it shows the weight which was calibrated last time. Use numeric key to change the weight, and then put the required weight on the plate. And then press 【print】 key to finish calibration.

2. Zero calibration

In the weighing model, press and hold 【print】 key, and then press 【ZERO】 key, it shows ECF-1. And then press 【net/gross】 key, it shows ECF-2. Press 【print】 key, it shows CAL Z. Press 【print】 key to calibrate zero and back to weighing model.

3. Weight calibration

In the weighing model, press and hold 【print】 key, and then press【ZERO】 key, it shows ECF-1. And then press【net/gross】 key twice, it shows ECF-3. Press 【print】 key, it shows the weight which was calibrated last time in the Weighing Window. Use numeric key to change the weight, and then put the required weight on the plate. And then press 【print】 key to finish calibration.

Error Messages

Err H	Initial zero too high (over 10% of max. cap.)
Err L	Initial zero too low (less than 10% of max. cap.)
Err N	Unstable internal value
hhhhhh	Overload, over the max. capacity + 9d
-----	Total price exceeded 999999

Remark

0	0	0
A	B	C

A: Buzzer on: 0= Stable not required 1= Stable required

B: LCD indicator and RELAY on: 0= Stable not required 1= Stable required

C: Buzzer beeps when: 0= Buzzer off 1= OK 2= LO and HI