



Model no.: M02

User's Manual

110609010023
V01.00.06_01

©2015, Shenzhen General Measure Technology Co., Ltd reserves all copyright.

Without permission from Shenzhen General Measure Technology Co., Ltd.,

Any corporations or person must not copy, spread, record or translate into other language by any forms.

Our company reserved the right to update user's manual without additional notice to customers by reason of update, so please visit our website or contact with our service person to get update information.

Website: <http://www.szgmt.com.cn>

CONTENTS

1 General Description.....	1
1.1 Functions and Characteristics.....	1
1.2 Front Panel.....	2
1.3 Rear Panel.....	4
1.4 Technical Specifications.....	4
1.4.3 Digital:.....	5
2 Installation and Wiring.....	6
2.1 Connection of Power Supply.....	6
2.2 Connection of Load Cell.....	6
2.2.1 6 wires connection.....	7
2.3 I/O terminals.....	8
2.4 Optional Expansion Board Output.....	9
2.4.1 Serial Interface RS485 Output.....	9
2.4.2 Serial Interface RS232 output (Optional).....	11
3 Calibration.....	12
3.1 Instruction.....	12
3.2 Flow Chart of Calibration.....	13
3.3 Millivolt Value Display.....	18
3.4 Calibration with Weights.....	19
3.5 Millivolt Calibration.....	19
3.6 Calibration Switch for Communication Interface.....	22
3.7 Explanation for Calibration Parameters.....	22

4 Working Parameters Setting.....	24
4.1 Flow Chart of Working Parameters Setting.....	24
4.2 Parameter Setting Method.....	26
4.3 Descriptions of Operation Parameters.....	27
4.4 Set point parameters.....	30
5 I/O Definition.....	32
5.1 I/O Definition.....	32
5.2 I/O testing.....	35
6 Serial Communication.....	37
6.1 r-Cont.....	37
6.2 r-SP1.....	38
6.2.1 Parameters Code Chart.....	38
6.2.2 Error Code Explanation.....	41
6.2.3 Command.....	41
6.3 tt TOLEDO Protocol.....	49
6.4 Cb920.....	50
6.5 rECont.....	51
6.6 rEREAD.....	52
6.7 Modbus.....	53
6.7.1 Modbus communication address.....	54
7 Ethernet communication.....	62
8 Password Input and Setting Reset.....	63
8.1 Password Input.....	63

8.2 Password Setting.....	63
8.3 Factory Reset.....	65
9 Display Testing.....	67
10 Errors and Alarm Messages.....	68
11. Indicator model user-defined function.....	69
12 Dimension of Indicator.....	70

1 General Description


M02 digital indicator is specially designed for weight transmitting in industrial fields.

This indicator has the features of small volume, plenty communicating commands, stable performance, easy operation and practicability. It can be widely applied to concrete and bitumen mixing equipment, metallurgy furnace and converter, chemical industry and feed, etc. .

1.1 Functions and Characteristics

- Small volume, unique design, easy operation
- Applicable to all kinds of resistance strain gauge bridge load cell
- Front panel numerical calibration
- Multilevel of digital filter
- Automatic zero -tracking
- Automatically zero when powered on
- 4 set points
- 1 input and 2 outputs
- Optional communication interface:RS232 or RS485
- Calibration via serial interface or Ethernet

1.2 Front Panel



Main Display: 6 digits, for displaying weight and the information of parameters.

Status Indicator Lamp:

- **ZERO:** Light on when present weight is within $0 \pm 1/4d$. the state of I10.
- **STAB:** Light on when changes of weight values are within the range of motion detecting during motion detecting time.
- **NET:** Light on when indicator is in net weight status.

Keypad:



: Zero/Esc, exit from current operation or go previous. Long press the ZERO button to calibrate the ZERO point function. The calibration range of the ZERO point in the main interface is limited by the ZERO clearing range, and cannot exceed the zeroing range, but it is not limited by

TARE
OPTION



: Scroll optional values of parameter and to make flashing digit increase 1 while data inputting. Long press Tare key will proceed data transmission, and the light will be flicker, and update the F1.8 parameters



: Function selecting key, make flashing position move to the right digit when data inputting.


W/A
ENTER



: Confirming Key. Confirm setting parameters or calibration and input data.

Note: Under the status of gross weight, user could remove tare by pressing OPTION key, and if press Esc key in net weight mode, it will add tare weight, while it is zeroing under the status of net weight. It will show net weight value after tare, meanwhile the NET light is on.

1.3 Rear Panel



1.4 Technical Specifications

1.4.1 Common:

Power supply: **DC24V \pm 5%**

Working temperature: **-10~40°C**

Max humidity: **90%R.H without dew**

Power consumption: **About 10W**

Dimension: **105×89×57 (mm)**

1.4.2 Analog:

Load cell power: **DC5V 200mA (MAX)**

Input impedance: **10MΩ**

Zero steady range: **0.00~12mV(Load cell 3mV/V)**

Input sensitivity: **0.1uV/d**

Input range: **0.00~15mV(Load cell 3mV/V)**

Transfer mode: **Sigma - Delta**

A/D conversion speed: **15, 30, 60, 120, 480, 960 times/sec**

Non-linearity: **0.01% F.S**

Gain drift: **10PPM/°C**

Display Precision: **1/100,000**

1.4.3 Digital:

Weight display: **6 digits red high-brightness LED**

Minus display: **"-"**

Overload display: **"OFL"**


Decimal point: **5 kinds (optional)**

Function keys: **4 keys soniferous keypad**

2 Installation and Wiring

2.1 Connection of Power Supply

M02 digital indicator connects DC24V power supply as follows:



Power supply connection

2.2 Connection of Load Cell


M02 digital indicator connects bridge type resistance strain gauge load cells by 6 wires or 4 wires as follows. When you use 4-wired load cells, you must bridge the SN+ with EX+ and bridge the SN- with EX-.

The signal definition of each port of the load cell connector is as follows:

EX+: Excitation+ **EX-:** Excitation- **SN+:** Sense+ **SN-:** Sense- **SIG+:** Signal+ **SIG-:** Signal-

6 wires	EX+	SN+	EX-	SN-	SIG+	SIG-	Shield
4 wires	EX+		EX-		SIG+	SIG-	Shield


2.2.1 6 wires connection



Note:

1. As load cell output sensitive analog signal, please use shield cable to separate with other cables, especially AC power.
2. 4 wires connection is suitable for short distance and stable temperature or low precision field, otherwise use 6 wires connection.
3. For more load cells parallel connection, their sensitivity (mV/V) should be same.


2.3 I/O terminals




I/O tolerant definition as follows:

Output		Input	
OUT1	Stable	IN1	Reset all
OUT2	OFL		

Indicator input terminal connection:



Indicator input terminal connection:




2.4 Optional Expansion Board Output

M02 digital indicator supports RS232 or RS485 as optional output function, please confirm it when place orders.

2.4.1 Serial Interface RS485 Output


Serial Interface RS485 output is optional, please refer to chapter 6.0 for communication protocol.

RS485 serial interface connection:



2.4.2 Serial Interface RS232 output (Optional)

RS232 serial interface connection:



3 Calibration

3.1 Instruction

(1) Calibration procedure must be executed when a M02 indicator is put in use at the first time, the preset parameters may no longer meet the user's needs, and any part of the weighing system was changed. Position of decimal point, minimum division, maximum capacity, zero, and gain can be set and confirmed through calibration.

(2) If you want to set only one parameter, please press  to save parameter's

value and then press  to exit.

(3) Please see section **3.7** for parameters' instruction.

- (4) Please record each value in the blank table in section 3.4 during calibration for the emergency use in future.
- (5) See chapter 9 for error alarm message that may be displayed during calibration.

3.2 Flow Chart of Calibration

 ⇔

Normal Status

1. Under this status, press  (twice),

indicator will display **CAL**, then

press  to enter password input.

 ⇔

Password input

2. After password is input, the indicator will display **CALON** for one second, then go to next step.

888888



Decimal point



3. Press to select a desired value for decimal point among 0, 0.0, 0.00, 0.000 and 0.0000, and then press to save it and enter next step. If there's no need to change the value, press directly to enter next step.

888888



Min. division



4. Press to select a desired value for min. division among 1,2, 5,10,20 and 50, and then to save it and enter next step. If there's no need to change the value, then press directly to enter next step.

888888



Max. capacity



5. Input max. capacity(\leq min. division \times 100000), press to save it and enter next step. If there's no need to change the value, then press directly to enter next step.

888.888



Millivolt value display

888.888

Zero calibration



6. Under this status, press



to enter zero calibration.

Display value near the output value in millivolt between **SIG+/SIG-** of load cell.
See section [3.3](#) for details about this function.



7. Unloaded scale first, when **STAB** lamp is on,

press



to finish zero calibration.

If there's no need to calibrate zero,

press




directly to enter gain calibration.

8. The process of gain calibration is as follows. If there's no need to do gain calibration, press



directly to enter serial ports calibration switch setting.

Gain Calibration



Serial ports
calibration switch



Password setting



Normal status



9. Press  to enter setting interface,
press  to choose the switch position,
press  to set password. If don't need to set
switch position, then press  to enter password
setting.

10. See section 7.2 for reference to set password.
If there's no need to set password,

press  directly to go back to normal
status.

3.3 Millivolt Value Display

This function is mainly used for system test, position-error test for weighing mechanism and linearity test for load cell.

1. System Test

(1) If display data changes with loaded weight changes, it shows that connection of load cell is correct and weighing mechanism works well.

(2) If display value is OFL (or -OFL), it means that loaded weight on load cells is too large (or too small). Please unload the weight (or load more), if display value is still OFL (or -OFL), the possible reasons are as follows:

- a. There is something wrong with weighing mechanism, please check and clear.
- b. The connection of load cell is incorrect, please check and clear.
- c. Load cells may be damaged, please replace.

2. Position-error Test for Weighing Mechanism

Load a same weight on each corner of weighing mechanism and record displayed millivolt value respectively. If differences among these values are obvious, please adjust weighing mechanism.

3. Linearity Test for Load Cell

Load same weight for several times, and record displayed value every time. If one or two values are obviously much larger or smaller than any others, it means that the linearity of load cell is bad.

*NOTE: Press



to zero every time before weight is loaded.

3.4 Calibration with Weights


During calibration with weight, please record the zero millivolt value, gain millivolt value and the loaded weight value in the blank table below. If it is not convenient to load a weight to calibrate, these values can be used for calibration without weights.


	Zero millivolt value(mV)	Gain millivolt value(mV)	Loaded Weight	Date	Remarks
1					
2					
3					
4					
5					

3.5 Millivolt Calibration

When it is not convenient to load a weight to calibrate, alibration can be done without weights using recorded data in the table in section 3.4.

However, this method is just used for some emergencies, it will make calibration result incorrect if load cells, or indicator has been replaced.





3.6 Calibration Switch for Communication Interface

When calibrate the transmitter through serial port(Rs、SP1 or Modbus), must set to “ON” status for the calibration switch for communication interface.

3.7 Explanation for Calibration Parameters


Symbol	Parameter	Types	Value of parameter	Default
Pt	Decimal Point	5	0 0.0 0.00 0.000 0.0000	0
1d	Min. Division	6	1 2 5 10 20 50	1
CP	Max. Capacity		≤Min. Division×100000	10000
t	Millivolt Value			
o	Zero			
C	Gain			
SIOCAL	Switch for Calibration via serial interface			OFF
PASS	Password Setting			000000


Log Table for Calibration Parameters

Parameter	Calibrated Value	Date	Remarks
Decimal Point			
Min. Division			
Max. Capacity			
Load cell sensitivity			
Password			

4 Working Parameters Setting

4.1 Flow Chart of Working Parameters Setting






4.2 Parameter Setting Method

M02 has 2 kinds of working parameters: Selection type and data type. For


selection type parameters, press  to choose. For data type parameter in

parameter interface, press  to choose digit position, press  to set value.

Selection:



Data:



4.3 Descriptions of Operation Parameters

Code	Default	Description
F1	Null	The first major term of working parameter.
F1.1	OFF	Switch for Auto-Zeroing when power-on, OFF: disabled ON: enabled
F1.2	0	Zero-tracking Range (0~9d optional) . This parameter is for automatic calibration, disabled when is set "0".
F1.3	0	Motion Detecting Range (0~9d optional) It is stable if the change is within range.
F1.4	50	Zeroing Range (00%~99% of Maximum capacity)
F1.5	5	Digital filtering parameter: (1-9 as optional) 0: without filtering 9: strongest digital filtering
F1.6	0	Stable filter parameter (the second filter based on the first filter) : (1-9 as optional) 0: without filtering 9: strongest digital filtering
F1.7	0	A/D conversion rate: 120,480,960,15,30,60 as optional

F1.8	0	0 : NET indicating net weight ; 1 : NET indicating communication
F2	Null	The second major term of working parameter.
F2.1	01	Scale no., indicator no.
F2.2	9600	Baud rate of serial port:1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600
F2.3	Cb920	Serial ports communication mode: Modbus-RTU: MODBUS RTU mode; r-Cont:SP1 continuous mode; r-SP1: SP1 command mode; tt:TOLEDOcontinuous mode; Cb920: Cb920 continuous mode. rE-Cont:rE continuous mode; rE- rEAd:rEcommand mode;
F2.4	7-E-1	Data format: 7-E-1: 7 data bit, even parity check, 1 stop bit; 7-O-1: 7data bit, odd parity check, 1 stop bit; 8-E-1: 8 data bit, even parity check, 1 stop bit; 8-O-1: 8 data bit, odd parity check, 1 stop bit;

		8-n-1: 8 data bits, no parity check, 1 stop bit; 8-n-2: 8 data bits, no parity check, 2 stop bits;
F2.5	HiLo	MODBUS dual-byte register storage turn, Hi Lo: High byte in the front, low byte at the back; Lo Hi: Low byte in the front, high byte at the back
F2.6	nONE	Cont mode automatic sending time interval
F2.7	0	tt(TOLEDO continuous mode) If send the checksum. 0: not send, 1: send.
F3	Null	The third major term of working parameter.
F3.1	0-255	The first paragraph of IP, initial vale 192
F3.2	0-255	The second paragraph of IP, initial vale 168
F3.3	0-255	The third paragraph of IP, initial vale 1
F3.4	0-255	The fourth paragraph of IP, initial vale 1
F3.5	1-65534	Modbus-TCP communication port no., initial value 502
F3.6		Ethernet communication mode 0: b Tcp; 1: Cont
F4	Null	The fourth major term of working parameter.
F4.1	OFF	Parameters password setting switch.
F4.2	000000	Parameters password setting: Valid when F4.1 is ON

4.4 Set point parameters

Code	Default	Description
P1-P4	Null	The first term of working parameters
PX.1	OFF	Change of state if need stable
PX.2	0.0	Change of state minimum duration
PX.3	P1.3=1 P2.3=5 P3.3=0 P4.3=0	Condition of validity: 0: forbid; 1: <; 2: <=; 3: ==; 4: >=; 5: >; 6: !=; compare to minimum value 7: _<>_outside the range, need to set 2 edge value 8: =<__>=inside the range, need to set 2 edge value 9: external trigger. If it's IO, do 1 state change for 1 trigger, if it's command, then decide according to valid or invalid command.
PX.4	0	Set value 1 (Set value 1 and set value 2, choose the minimum to compare)

PX.5	0	Set value 2
------	---	-------------

Set point has **4** major terms which are user defined.

5 I/O Definition

5.1 I/O Definition

In the main display interface, press **MODE** ► 4 times to display iodEF in the indicator. In this interface, press   to enter the interface of custom setting of I/O module. If the password ON/OFF of working parameter F4.1 is set as ON, the password of working parameter needs to be entered before entering the custom setting of I/O module.

Operation steps of I/O module customization: After entering the interface of I/O module customization,

- 1) Press   to modify the definition of OUT1
- 2) Press   ▲ to select the meaning code of I/O module
- 3) Press   to confirm and return to the OUT1 interface

- 4) Press **MODE ►** to define the next I/O module, then press **MODE ►** to skip the current I/O module definition (keep the original definition) to set the next I/O module. The definition method is the same as the above three steps, which will not be repeated here. Press **ZERO ESC ■** to exit when the setup is complete.

Output/Input code table:

Output		
Code	Definition	Description
O0	None	No definition
O1	Stable	Effective output in stable status.
O2	Overflow	Effective output when overflow.
O3	Sp1	Effective output when set point 1 status output.
O4	Sp2	Effective output when set point 2 status output.

O5	Sp3	Effective output when set point 3 status output.
O6	Sp4	Effective output when set point 4 status output.

Input

Code	Definition	Description
I0	None	No definition
I1	Zeroing	Effective input for zeroing, pulse input signals
I2	Sp1	If this signal is valid, Sp1 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I3	Sp2	If this signal is valid, Sp2 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I4	Sp3	If this signal is valid, Sp3 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.

I5	Sp4	If this signal is valid, Sp4 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I6	Reset all	Reset all parameter value when this signal is valid.
I7	Tare/Add tare	Tare when the first valid signal. Add tare when second.
I8	Tare	Tare when the signal is valid.
I9	Add tare	Add tare when the signal is valid.
I10	I/O define	IO calibration lock, when I10 is defined, cannot be calibrated if the input is invalid.

5.2 I/O testing

8.8.8.8.18

Normal Status

Under weighing status, press  (5 times), then display TESTIo, press  enter into I/O testing interface.

Press  OUT1 status flash, press  OUT2

 ⇔ ⇔

This interface shows: **IN1** input valid, **OUT1** output valid.

6 Serial Communication

M02 has RS232 or RS485 as optional to realize communication with host computer and support r-Cont、r-SP1、Modbus(bus)、tt TOLEDO、Cb920、rECont protocols and rErEAD protocol.

Serial communication terminal please refer to chapter 2.4.2、2.4.3. Baud rate and communication format setting please refer to F2.2、F2.3 and F2.4.

※Under main display (display weight value), long press  to enter into serial communication checking interface, it will display '-----' if no communication, and '-----' will flash if there's communication.

6.1 r-Cont

Indicator will send weighing data to host computer without command.

Data Format:

STX	Scale no.	Channel no.	Status	Value	CRC	CR	LF

Here:

STX —— 1byte, start character **02H**

Scale no. —— 2bytes, **00~99**

Status —— 2bytes, high byte:**40H**; low byte definition as follows:

D6	D5	D4	D3	D2	D1	D0
Null	Null	G./N. weight	+/-	Zero point	OFL	Stable
1	0	0	0: + 1: -	0: non/zero 1: zero	0: normal 1: OFL	0: not stable 1: stable

Weight Value —— 6 bytes; when weight is+(-)overflow,return to“space space **OFL** space”

CRC —— 2 bytes,check sum

CR —— 1 byte, **0DH**

LF —— 1 byte, **0AH**

For example:

02 30 31 31 40 41 20 20 20 37 30 30 32 34 0D 0A

Means: stable,positive data,present weight 700

6.2 r-SP1

Code : **ASCII**

Operation code supported: **W**, write; **R**, read; **C**, calibrate; **O**, zero

6.2.1 Parameters Code Chart

Operation code	Para. code	Para. Name	number of character
R	WT	Read current status	8

		and weight	
R	SP	Read set point status	4
W	DC	Write mini. Division and max. capacity	8
R/W	PT	Decimal point digit	1
R	DD	Minimum division	2
R	CP	Maximum capacity	6
R/W	AC	Auto. Zeroing switch	1
R/W	TR	Zero tracking range	1
R/W	MR	Stable range	1
R/W	ZR	Zeroing range	2
R/W	FL	digital filtering para.	1
R/W	VC	steady filtering	1
R/W	AD	AD sample rate	1
R	PO	Set point output status	4
R/W	P1M~P4M	Set point to judge if need stability	1
R/W	P1T~P4T	Set point minimum duration time	3
R/W	P1F~P4F	Set point comparison condition to judge	1
R/W	P1L~P4L	Set point lower edge value to judge	6
R/W	P1H~P4H	Set point upper edge value to judge	6

R	AM	Absolute millivolt	7: D6D5D4D3D2D1D0; D6:+;D5-D0: corresponding ASCII for 6 digits millivolt,Decimal point is fixed to 3 digits
R	RM	Relative zero point on millivolt	7: D6D5D4D3D2D1D0 D6 : +/;-D5-D0: corresponding ASCII for 6 digits, Decimal point is fixed to 3 digits
C	ZY	Zero calibration with weight	
C	ZN	Zero calibration without weight	6
C	GY	Gain calibration with weight	6
C	GN	Gain calibration without weight	12
O	CZ	Zero clearing command	
O	P1S~P4S	Setting the corresponding set point	Valid when 9,command valid when external trigger and 1 status change for 1 external Trigger
O	P1C~P4C	Clear the corresponding set point	
R	ID	Read ID No.	6

6.2.2 Error Code Explanation

In the communication mode, if the weight transmitter receives a data frame error, there will be an error code in the data frame sent to the computer. The error code is described as follows:

- 1: CRC check error
- 2: Operation code error
- 3: Parameters code error
- 4: Write data error
- 5: Operation invalid
- 6: Channel no. error

Note: Default channel no. of this indicator : 1 (31H)

6.2.3 Command

Indicator will send weighing data to host computer after received command.

6.2.3.1 Host computer read present status

Send command:

STX	Scale no.	Channel No.	R	WT	CRC	CR	LF
-----	-----------	-------------	---	----	-----	----	----

Correct response:

STX	Scale no.	Channel No.	R	WT	Status	Value	CRC	CR	LF
-----	-----------	-------------	---	----	--------	-------	-----	----	----

Wrong response:

STX	Scale	Channel	R	WT	E	Error code	CRC	CR	LF
-----	-------	---------	---	----	---	------------	-----	----	----

	no.	No.						
--	-----	-----	--	--	--	--	--	--

Here:

STX —— 1byte, start character, **02H**

R——1 byte, **52H**

WT——2 byte, **57H 54H**

E——1 byte, **45H**

Status —— 2bytes, high byte: **40H**; low byte definition as follows:

D6	D5	D4	D3	D2	D1	D0
Null	Null	G./N. weight	+/-	Zero point	OFL	Stable
1	0	0	0: + 1: -	0: non/zero 1: zero	0: normal 1: OFL	0: not stable 1: stable

Weight Value —— 6 bytes: when weight is+ (-) overflow,return to“space space **OFL** space”

For example:

02 30 31 31 52 57 54 30 31 0D 0A

Correct response: **02 30 31 31 52 57 54 40 41 30 30 33 37 35 33 33 36 0D 0A** (stable present value **3753**)

Wrong response: **02 30 31 31 52 57 54 45 31 31 39 0D 0A** (CRC check error)

6.2.3.2 Read other parameters

Send command:

STX	Scale no.	Channel No.	R	Para. code	CRC	CR	LF
------------	-----------	-------------	----------	-------------------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	R	Para. code	Value	CRC	CR	LF
------------	-----------	-------------	----------	-------------------	-------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	R	Para. code	E	Error code	CRC	CR	LF
------------	--------------	----------------	----------	-----------------------	----------	------------	------------	-----------	-----------

Para. Value—1byte

Para. code—2 bytes,

For example:

02 30 31 31 52 4D 52 38 39 0D 0A

Correct response: 02 30 31 31 52 4D 52 36 34 33 0D 0A (stable range: 6)

Wrong response: 02 30 31 31 53 4D 52 45 32 30 39 0D 0A (Operation code error)

6.2.3.3 Write max. Capacity and min. Division

Send command:

STX	Scale no.	Channel No.	W	DC	Division value	Max. capacity	CRC	CR	LF
------------	--------------	----------------	----------	-----------	-------------------	------------------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	W	DC	O	K	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	W	DC	E	Error code	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here:

DC—2 bytes, **44H 43H**

O—1 byte, **4FH**

K—1 byte, **4BH**

Division value—2 bytes, **1/2/5/10/20/50**

Max. capacity—6 bytes

For example:

02 30 31 31 57 44 43 30 35 30 31 30 30 30 30 36 30 0D 0A(division value 5, Max capacity 10000)

Correct response: **02 30 31 31 57 44 43 4F 4B 32 34 0D 0A**

Wrong response: **02 30 31 31 57 44 43 45 35 39 32 0D 0A** (Operation can't execute)

6.2.3.4 Write other parameters

Send command:

STX	Scale no.	Channel No.	W	Para. code	Para. value	CRC	CR	LF
------------	-----------	-------------	----------	-------------------	-------------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	W	Para. code	O	K	CRC	CR	LF
------------	-----------	-------------	----------	-------------------	----------	----------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	W	Para. code	E	Error code	CRC	CR	LF
-----	-----------	-------------	---	------------	---	------------	-----	----	----

For example:

02 30 31 31 57 5A 52 35 30 30 38 0D 0A (Write zeroing range to 50)

Correct response: **02 30 31 31 57 5A 52 4F 4B 36 31 0D 0A**

Wrong response: **02 30 31 31 57 5A 53 45 33 32 38 0D 0A** (Para. Code error)

6.2.3.5 Calibration Zero

1) Calibrate zero as per current weight (with weight)

Send command:

STX	Scale no.	Channel No.	C	ZY	CRC	CR	LF
-----	-----------	-------------	---	----	-----	----	----

Correct response:

STX	Scale no.	Channel No.	C	ZY	O	K	CRC	CR	LF
-----	-----------	-------------	---	----	---	---	-----	----	----

Wrong response:

STX	Scale no.	Channel No.	C	ZY	E	Error code	CRC	CR	LF
-----	-----------	-------------	---	----	---	------------	-----	----	----

Here:

Z—1 byte, 5AH

Y—1 byte, 59H

For example:

02 30 31 31 43 5A 59 39 34 0D 0A

Correct response: **02 30 31 31 43 5A 59 4F 4B 34 38 0D 0A**

Wrong response: **02 30 31 34 43 5A 59 45 36 32 30 0D 0A** (channel no. error)

2) Input millivolt calibration zero in the chart (without weight)

Send command:

STX	Scale no.	Channel No.	C	ZN	Zero millivolt value	CRC	CR	LF
------------	-----------	-------------	---	-----------	----------------------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	C	ZN	O	K	CRC	CR	LF
------------	-----------	-------------	---	-----------	---	---	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	C	ZN	E	Error code	CRC	CR	LF
------------	-----------	-------------	---	-----------	---	------------	------------	-----------	-----------

Here:

ZN—2 bytes, 5AH4EH

Zero millivolt value—6 bytes

For example:

02 30 31 31 43 5A 4E 30 31 32 36 31 30 38 31 0D 0ACorrect response:**02 30 31 31 43 5A 4E 4F 4F 4B 33 37 0D 0A**Wrong response:**02 30 31 31 43 5A 4E 45 34 30 34 0D 0A** (Write data error)**6.2.3.6 Gain calibration****1) With weights**

Send command:

STX	Scale no.	Channel No.	C	GY	Weight value	CRC	CR	LF
------------	-----------	-------------	---	-----------	--------------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	C	GY	O	K	CRC	CR	LF
------------	-----------	-------------	---	-----------	---	---	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	C	GY	E	Error code	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here:

GY—**2 bytes**, **47H 59H**

Weight value—**6 bytes**: Write in weight value

For example:

02 30 31 31 43 47 59 30 30 30 32 30 30 36 35 0D 0A (Write in: weight value **200**)

Correct response: **02 30 31 31 43 47 59 4F 4B 32 39 0D 0A**

Wrong response: **02 30 31 35 43 47 59 45 36 30 32 0D 0A** (Channel no. error)

2) Without weights

Send command:

STX	Scale no.	Channel No.	C	GN	Gain millivolt	Weight value	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------------	--------------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	C	GN	O	K	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	C	GN	E	Error code	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here:

Gain millivolt—**6 bytes**

Weight value—**6bytes**

For example:

02 30 31 31 43 47 4E 30 30 31 39 34 30 30 30 32 30 30 35 36 0D 0A (Write in:

weight value **200**, corresponding gain millivolt **0.194**)

Correct response: **02 30 31 31 43 47 4E 4F 4B 31 38 0D 0A**

Wrong response: **02 30 31 31 43 48 4E 45 33 38 35 0D 0A** (Para. Code error)

6.2.3.7 Zeroing

Send command:

STX	Scale no.	Channel No.	O	CZ	CRC	CR	LF
------------	-----------	-------------	----------	-----------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	O	CZ	O	K	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	O	CZ	E	Error code	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

For example:

02 30 31 31 4F 43 5A 38 34 0D 0A

Correct response: **02 30 31 31 4F 43 5A 4F 4B 33 38 0D 0A**

Wrong response: **02 30 31 31 4F 43 5A 45 35 30 36 0D 0A** (Operation can't execute)

6.2.3.8 CRC computation

All the values in front of the parity byte add together and convert to decimal data, then convert the last 2 bytes to **ASCII** code (decade in front and the unit at the back).

For example

The following is a frame of data:

0	3	3	3	4	4	5	3	3	0	0
----------	----------	----------	----------	----------	----------	----------	----------	----------	----------	----------

Add 02~5A: 180(Hex), convert to decimal data: 384. We can calculate from this that the check code is 38,34 for the data frame.

6.3 tt TOLEDO Protocol

When choose "tt" protocol in working parameter F2.3, indicator will send datas in continuous mode with TOLEDO protocol.

Continuous sending mode format as below:

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
STX															0D		

~ A B C display weight(6 bytes) 6pcs 30H

Checksum

Here: start character is standard **ASCII** start character **02(STX)**

status byte **A** definition as below:

D0	0	1	0	1	0
D1	1	1	0	0	1
D2	0	0	1	1	0

Decimal point	x	.x	.xx	.xxx	.xxxx
---------------	---	----	-----	------	-------

D3 D4 D6 is 0(not change) D5 is 1(not change)

status byte **B** definition as below:

D6	D5	D4	D3	D2	D1	D0
Status			Stable	Overflow	symbol	G.W.
Is 0 (not change)	Is 1 (not change)	Is 1 (not change)	1-unstable 0-stable	1-overflow 0-normal	1-negative 0-positive	Is 0 (not change)

status byte **C** is reserved, output 20H.

6.4 Cb920

When F2.3=Cb920 in working parameter, indicator will send weighing data continuously without command under **Cb920** protocol.

Data format:

Status	,	G.W.	0/1	Symbol	Display	Unit	CR	LF
--------	---	------	-----	--------	---------	------	----	----

Here :

Status —— **2 bytes**, **OL:** (**4FH 4CH**) OFL; **ST:** (**53H 54H**)Stable; **US:** (**55H 53H**)unstable
, —— **1 byte**, separator **2CH**

G.W. —— **2 bytes**, **GS:** gross weight **47H 53H**
0/1 —— **1 byte**, (30H/31H) interleaved transmission

Symbol —— **1 byte**, **2BH (+)** , **2DH (-)**

Display —— **7 bytes**, including decimal point

Unit —— **2 bytes**, blank space (**20H 20H**)

CR —— **1 byte**, **0DH**

LF —— **1 byte**, **0AH**

For example: When indicator send the following automatically:

53 54 2C 47 53 31 2B 20 20 31 39 30 2E 31 20 20 0D 0A

Means: Stable、G.W.、Data value is positive、current weight is **190.1**

6.5 rECont

Indicator will send weighing data to the upper computer continuously without any command.

Return data frame format specification:

Status	,	GS	,	+/-	Display	Unit	CR	LF
2bytes	2C	47 53	2C	2B/2D	7bytes	6B 67	0D	0A

Here:

Status —— **2 bytes**, OL(OFL):**4FH 4CH**; ST(stable):**53H 54H**; US(unstable):**55H 53H**

Display value —— **7bytes**, including decimal point, high byte is blank if no decimal point.

For example: When indicator send the following automatically:

53 54 2C 47 53 2C 2B 30 31 31 2E 31 32 30 6B 67 0D 0A

Means: Stable, Data value is positive, display value is **11.120kg**

6.6 rEREAD

Indicator will send weighing data to the upper computer under command.

Data format:

Data	R	E	A	D	CR	LF
explain	52H	45H	41H	44H	0DH	0AH

The return data frame is the same with that of **rECont** protocol, please refer to **rECont**.

- 1) Zero clearing command: ZERO ON<CR><LF> : **5A 45 52 4F 20 4F 4E 0D 0A**
Return YES<CR><LF> or NO? <CR><LF>
- 2) Calibration zeroing command: TARE ON<CR><LF> : **54 41 52 45 20 4F 4E 0D 0A**
Return YES<CR><LF> or NO? <CR><LF>
- 3) Read ID no.: GET ID<CR><LF> : **47 45 54 20 49 44 0D 0A**
Return ASCII code with 6 digits ID no.

6.7 Modbus

Indicator uses **RTU mode or ModBus-TCP mode** to communicate, every 8-byte byte of the message are divided into 2pcs of 4-byte hexadecimal characters to transmit at binary code.

Code: Binary

Function code:

Function code	Definition	Description
03	read the register	
06	preset single register	
16	preset several registers	Command only support preset double registers.

01	read coil	The length unit is byte.
05	write coil	

Exception code response

Code	Definition	Description
02	Illegal data address	Data address received from error code is not allowed
03	Illegal data value	Data wrote in is not in permissible range
04	machine fault	When indicator is trying to execute operation required, unrecoverable error is produced.
07	Unsuccessful programming request	Command received can't be executed under current condition.

6.7.1 Modbus communication address

PLC addr.	Display addr.	Description
The following items are only-read register(code 0x03)		
40001	0000	Present weight value(4bytes including sign characters, the high byte is in the front)
40002	0001	

40003	0002	D15—D14..D5—D4 — D3 — D2 — D1 — D0 All is 0 0:+ 0:non-zero 0:normal 0:unstable 1:- 1: zero 1:OFL 1:stable
40004	0003	
.....	Reserve(permit to read, reading value is 0)
The following items are two bytes and are available to read and write (write code 0x06, read code 0x03)		
40007	0006	Zeroing(zeroing when write in non-zero value)
40008	0007	Automatically zeroing when power on (0: OFF; 1: ON)
40009	0008	Zero tracking range (0-9d)
40010	0009	Stable range (0-9d)
40011	0010	Zeroing range (0%-99%)
40012	0011	Digit filter parameters(0-9)
40013	0012	Stability filter series(0-9)
40014	0013	AD sample rate: 0:15/s 1:30/s 2:60/s 3: 120 /s 4:480/s 5:960/s
40015	0014	Reserved
40016	0015	Communication indicating switch

		0: NET indicating net weight; 1: NET indicating communication
40017~ 40018	0016~ 0017	Reserved
40019	0018	Decimal point place (0:0,1:0.0,2:0.00,3:0.000,4:0.0000)
40020	0019	Minimum division (1/ 2/ 5/ 10/ 20/ 50)
The following items are available to read and write (writing code 0x10, read code 0x03)		
40021	0020	Maximum capacity (max.capacity≤mini.division× 100000)
40022	0021	
40023	0022	Zero calibration with weights: write in 1 and calibrate zero with the current weight.
40024	0023	Read: Absolute millivolt of current load cell
40025	0024	Zero calibration without weights: Write millivolt value at zero; Write in range (load cell 3mV/V :millivolt value range within 0.02-12.000mV) millivolt value at zero when read.
40026	0025	
40027	0026	Gain calibration with weights. Write weight value(≤max. capacity). Return millivolt at present weight value when read
40028	0027	
40029	0028	Gain calibration without weights ; input gain millivolt(load

40030	0029	cell 3mV/V: 0.000 < millivolt< 15.000mV — zero millivolt). Read: millivolt value for gain calibration.
40031	0030	Gain calibration weight without weights. input gain millivolt(≤max. capacity) Read: weight value for gain calibration.
40032	0031	
40033	0032	Gross weight, with symbol.
40034	0033	
40035	0034	Net weight
40036	0035	
40037	0036	Tare weight
40038	0037	
40039~40040	0038~0039	reserved
40041	0040	Set point 1 stable or not (0: no; 1: yes)
40042	0041	Set point 1 min. duration time (0-999 : 0-99.9sec.)
40043	0042	Set point 1 valid condition
40044~40045	0043~0044	Set point 1 set value 1
40046~40047	0045~0046	Set point 1 set value2
40048	0047	Set point 2 stable or not (0: no; 1: yes)
40049	0048	Set point 2 min. duration time (0-999 : 0-99.9sec.)

40050	0049	Set point 2 valid condition
40051~40052	0050~0051	Set point 2 set value1
40053~40054	0052~0053	Set point 2 set value2
40055	0054	Set point 3 stable or not (0: no; 1: yes)
40056	0055	Set point 3 min. duration time (0-999 : 0-99.9sec.)
40057	0056	Set point 3 valid condition
40058~40059	0057~0058	Set point 3 set value 1
40060~40061	0059~0060	Set point 3 set value 2
40062	0061	Set point 4 stable or not (0: no; 1: yes)
40063	0062	Set point 4 min. duration time (0-999 : 0-99.9sec.)
40064	0063	Set point 4 valid condition
40065~40066	0064~0065	Set point 4 set value 1
40067~40068	0066~0067	Set point 4 set value 2
40069	0068	Output 1 user-defined
40070	0069	Output 2 user-defined
40071	0070	Input 1 user-defined
40072	0071	I/O output value Note: available only when coil address 00016 is valid.
40073	0072	I/O input value Input write 1 valid, 0 invalid.

			Read 1 valid, 0 invalid
40074	0073	Ethernet communication mode	0: b tcp; 1: Cont
Reserved			
40399	0398	Current weight value(4 bytes floating-point number , high digit in front)	
40400	0399		
40401	0400	Current weight value(4 bytes with symbolic number, high digit in front)	
40402	0401		
40403	0402	D15—D14.....D4 0 D3 0:+ 1:- D2 0:non-zero 1:zero D1 0:normal 1:OFL D0 0:Stable 1:Unstable	
40404	0403	0	
40405	0404	6 digits without symbolic number, user ID no.	
40406	0405		
The following items are byte read only. (read code: 0x03)			
49001	9000	Version no.	If display10024, formatXX XXXX,main

49002	9001		version no., hardware no., software no.. So main version no.01 , hardware no. 00, software no. 24
49003	9002		If display 141024, means 24 th Oct.,
49004	9003	Develop time	2014

The following items are byte read only. (read code: 0 x 0 1)

00001	0000	0: unstable; 1: stable
00002	0001	0: normal; 1: OFL
00003	0002	0: non-zero; 1: zero
00004	0003	0: +; 1: -
00005	0004	Reserved
00006	0005	Reserved

The following item are available to read and write
(read code: 0x01, writing code: 0x05)

00007	0006	Automatically zeroing when power on (0: OFF; 1: ON)
00008	0007	Reserved
00009	0008	Reserved
00010	0009	Reset all

00011	0010	Reset calibration	
00012	0011	Reset parameters	
00013	0012	Reset I/O	
00014	0013	Reserved	
00015	0014	Reserved	
00016	0015	I/O testing switch	
00017	0016	Set point 1 status	Only read: 0:invalid, 1:valid
00018	0017	Set point 2 status	
00019	0018	Set point 3 status	
00020	0019	Set point 4 status	
00021	0020	Reserved	
00022	0021		
00023	0022	Tare (Write ON to proceed)	
00024	0023	Add tare (Write ON to proceed)	
00025	0024	Net weight (0: Gross weight, 1: Net weight)	
00026~	0025~	Reserved	
00032	0031		

7 Ethernet communication

M02 digital indicator can connect with RJ-45 cable to communicate with host computer or PLC by Ethernet port.

User need set IP address in F3 working parameters. For example, if IP is 192.168.101.106, then input 192 at F3.1, input 168 at F3.2, input 101 at F3.3, input 106 at F3.4; input port no. at F3.5

After cable connected, orange light is bright for good communication and green light is sparkle in communication. The DATA light will sparkle in Modbus/TCP communication and will be off if the communication is broken.

8 Password Input and Setting Reset

8.1 Password Input

- (1) Indicator calibration and working parameters setting default password: **000000**.
- (2) User can set password in parameters when **F4.1** is“ON”.
- (3) When display is “PASS”, need to input correct password to enter parameters.


Note:

- (1) When input password, if first time wrong, it will go to the second chance for password input(display from **0-----** turn to **0-----0**).
- (2) If second input wrong, it will enter into interface for inputting password the third time
(Display change from **0-----0** to **0----E----E**).
- (3) If Input wrong for three times, main display show “Error4” and self-lock, but user can operate when power on again.

8.2 Password Setting

- (1) User can set password in parameters when **F4.1** is“ON”.


- (2) User must input same new password twice in setting password, If not same, main display show "Error" one second and return to **PASS** again.




8.3 Factory Reset

Note: Factory reset is only for special technicians, which will reset all of parameters and will maybe cause not working.

Take reset all for example:





1) In **F SET** interface, press to reset working parameters, enter into reset calibration parameters interface.

2) In **F SET** interface, press , not to make working parameter reset, enter into calibration para. Reset interface.

3) In **F CAL** interface, press to reset calibration para., enter into reset all interface.

4) In **F CAL** interface, press , not to make calibration para. reset, enter into reset all interface.


5) In **F ALL** interface, press to make reset all of the parameters (including working para., calibration para., I/O etc..)

Note: In all reset interfaces, press to exit and return to weighing interface.

9 Display Testing

The following flow chart is to test lights on main-display and status lights.

Normal weighing status



Press 5 times MODE

tEST



8.8.8.8.8.8



tEST

Under parameter interface,
press MODE to switch to "tEST" interface.

Under "tEST" interface, press
HOLD ENTER to make display testing,
Nixie tube display and indicator
lights all shine. Now if
press HOLD ENTER, display will
sparkle.

After testing is finished,
press ZERO ESC to return
to "tEST" interface.

10 Errors and Alarm Messages

Error ① Input error.

② wrong data beyond parameter range.

Error 2 The present weight value is out of zeroing range.

Error 3 Scale platform is not stable when zeroing.

Error 4 Input wrong password more than 3 times.

Error 5 Overlimit when tare.

Error 6 Weight value is not stable when tare.

OFL Weighing value is positive overflow.

-OFL Weighing value is negative overflow.

11. Indicator model user-defined function

Long press MODE to display "LOGO" and enter the setting interface. Press ZERO to return to the setting menu



After saving, the next boot will show the newly edited model number.(ModbusTCP does not add a write function.)Add files such as "LogoSetupThread. C "and" logosetuthread. H ".

Displays character comparison table

a ^o	b ^o	c ^o	d ^o	e ^o	f ^o	g ^o	h ^o	i ^o	j ^o	k ^o	l ^o	m ^o
A ^o	b ^o	C ^o	d ^o	E ^o	F ^o	G ^o	H ^o	I ^o	J ^o	K ^o	L ^o	ñ ^o
n ^o	o ^o	p ^o	q ^o	r ^o	s ^o	t ^o	u ^o	v ^o	w ^o	x ^o	y ^o	z ^o
ñ ^o	o ^o	P ^o	q ^o	r ^o	S ^o	E ^o	U ^o	U ^o	Y ^o	N ^o	Y ^o	Z ^o

12 Dimension of Indicator

Dimension of rear panel: **92×45(mm)**



Dimension of front panel: **105×57(mm)**

Panel cutout dimension: **93×46(mm)**

